



- Installation**
1. Drill approximately 0.25" Deep 1/4-28 Sensors; a 3 Drill Bit
  2. Spot Face Location Using 1/8" Chamfer
  3. Tap Hole for Required Thread Size
  4. If Not Drilled from Surface
  5. If Not Drilled from Surface, Use a Drilling Fluid and Sensor
  5. Install Sensor
- Suggested Mounting Kit**
- CNC2270-01-1 For 1/4-28 UNF Sensors
  - CNC2270-02-1 For NKS1.25 Sensors
  - CNC2270-03-1 For NKS1 Sensors

THIS DOCUMENT IS THE PROPERTY OF STI AND SHALL BE RETURNED TO STI WITHOUT DELAY. IT IS NOT TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, WITHOUT PERMISSION IN WRITING FROM STI.

CUSTOMER LOCATION ORDER NO.

UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN INCHES.

STI Vibration Monitoring League City, Texas

REV	DATE	BY	DESCRIPTION
1			
2			
3			
4			
5			

Notes:

- 1.
- 2.
- 3.
- 4.
- 5.

A

9

8

7

6

5

4

3

2

1

9

8

7

6

5

4

3

2

1

H

9

8

7

6

5

4

3

2

1

H

G

9

8

7

6

5

4

3

2

1

G

F

9

8

7

6

5

4

3

2

1

F

E

9

8

7

6

5

4

3

2

1

E

D

9

8

7

6

5

4

3

2

1

D

C

9

8

7

6

5

4

3

2

1

C

B

9

8

7

6

5

4

3

2

1

B

A

9

8

7

6

5

4

3

2

1

A